



Peroxall™ TB

HUSKY® 845

Ready-to-use hydrogen peroxide disinfectant powered by proprietary HydrOx+ Technology. This one-step formula delivers broad-spectrum disinfection with a 1-minute contact time against organisms including *Mycobacterium bovis* (TB), Norovirus, MRSA, and SARS-CoV-2. Also effective against Canine Parvovirus (5 minutes) and *Candida auris* (10 minutes). Ideal for hospitals, healthcare, long-term care, schools, veterinary, and commercial settings. Peroxall TB provides hospital-grade disinfection with a Caution signal word. No dilution or mixing, just spray and wipe.

Directions

To Use as a One-Step¹ Disinfectant⁴:

1. Pre-clean visibly soiled areas.
2. Spray 6 – 8 inches from surface¹, making sure to wet thoroughly.
3. Allow surface to remain visibly wet for 1 minute⁶. For SARS-CoV-2, treated surfaces must remain visibly wet for 30 seconds.
4. Wipe surface dry.



Broad-spectrum disinfection for everyday use.

Specs

Registrations: EPA Registered
EPA Reg. No: 6836-442-8155
Dilution: RTU
pH Level: 0.5–1.5
Color: Clear
Fragrance: Citrus
Pack Size: Quart

Features

- Cleans and disinfects in one step
- Convenient⁶ 1 minute hospital disinfectant
- Kills 99.9% of bacteria
- Free from bleach, peracetic acid, and alcohols
- Fresh citrus scent, no lingering residue or strong fumes
- Time-saving, cost-saving formula

Recommended For

- Acrylic
- Finished Woodwork
- Formica®
- Glass
- Glazed Ceramic & Porcelain
- Metal Plastic
- Sealed Granite,
- Marble & Quartz
- Stainless Steel
- Upholstery – Vinyl & Plastic
- Washable Hard, Non-Porous Surfaces



Peroxall™ TB

DISINFECTANT CLAIMS

Bacteria

- Acinetobacter baumannii – 1 min
- Corynebacterium bovis – 1 min
- Enterobacter aerogenes
- Enterobacter cloacae New Delhi Metallo-Beta-Lactamase 1 (NDM-1) – 1 min
- Enterococcus faecalis (Vancomycin Resistant) (VRE) – 1 min
- Enterococcus faecium – 1 min
- Escherichia coli – 1 min
- Escherichia coli O157:H7 – 1 min
- Klebsiella pneumoniae – 1 min
- Klebsiella pneumoniae (Carbapenem Resistant) – 1 min
- Klebsiella pneumoniae New Delhi Metallo-Beta-Lactamase 1 (NDM-1) – 1 min
- Mycobacterium bovis BCG (TB) at 21 °C – 1 min
- Pseudomonas aeruginosa – 1 min
- Salmonella enterica – 1 min
- Staphylococcus aureus – 1 min
- Staphylococcus aureus (Methicillin Resistant) (MRSA) – 1 min
- Staphylococcus aureus (Vancomycin Resistant) (VRSA) – 1 min

Fungi

- Candida auris – 10 min

Viruses*

- *Adenovirus Type 5 – 1 min
- *Hepatitis B Virus (HBV) – 1 min
- *Hepatitis C Virus (HCV) – 1 min
- *Herpes simplex type 1 Virus (HSV-1) – 1 min
- *Human immunodeficiency virus type 1 (HIV-1) – 1 min
- *Human Rotavirus – 1 min
- *Influenza A Virus – 1 min
- *Norovirus – 1 min
- *Rhinovirus type 37 – 1 min
- *SARS-Related Coronavirus 2 (SARS-CoV-2) (cause of COVID-19) – 30 seconds

Animal Viruses*

- *Canine Parvovirus – 5 min
- *Feline Calicivirus – 1 min
- *Minute virus of mice – 5 min

¹On hard, non-porous, non-food surfaces

⁴When directions for disinfection are followed

⁶5-minute contact time required for Canine Parvovirus efficacy claim; 10 minutes for Candida auris; 5 minutes for Minute Virus of Mice